

# ALLDOCUBE badgeuse

## File

[Firmware + bootloader](#)

## Unlock Bootloader

1. go in settings and urn on developer option
2. unlocking "oem"
3. activated adb

```
adb reboot bootloader
```

```
fastboot flashing unlock
```

on device press volume down (you have 3second)

```
fastboot flashing unlock_critical
```

on device press volume down (you have 3second)

## Flash Bootloader and Firmware

```
cd ~/rooting_tablette/Firmware/T811MAN
```

install Bootloader

```
fastboot flash boot magisk_patched-27000_MR09X.img
```

## unlock Bootloader verification

```
fastboot --disable-verity --disable-verification flash vbmeta_a vbmeta_a.original.img  
fastboot --disable-verity --disable-verification flash vbmeta_b vbmeta_a.original.img
```

## install Firmware

```
fastboot flash super superRW-WORK.img
```

## Clear partition

```
fastboot reboot fastboot && fastboot erase userdata && fastboot erase metadata && fastboot  
reboot
```

on device when in reboot on fastbootd choose "Reboot to bootloader"

Force reboot at end

# Finish installation

1. go in settings and turn on developer option
2. unlocking "oem"
3. activated adb
4. install magisk and launch app

```
adb install Magisk-v27.0.apk
```

Revision #2

Created 21 May 2024 09:14:51 by Fofure

Updated 21 May 2024 09:20:19 by Fofure